

## MBX-4 RR PARTS LIST

C0055	MBX-4 RR Kit (w/out Tire)	C0408	Wing Stay & Body Mount
C0056	Instruction Manual	C0451	Bumper F/R
C0057	Decal	C0452	Stone Guard
H0109	Toe in Adj. Rod	C0453	Body Mount & Tension Rod Mount
C0113	Turnbuckle Upper Arm (2 pcs.)	C0455	Chassis
C0114	Washer Set	C0508	Diaphragm
C0115	Upper Arm Link	D0509	O-Ring Set
C0122S	Lower Sus. Shaft S	H0513	Spring Adjuster
C0127B	Center Upper Plate	C0524	Front Damper Case
C0133	Rear Upright Bracket	C0526	Front Damper Shaft
C0150	Gear Box	C0528	Damper (Plastic Part)
C0154	Front Upper Arm	C0530	Dust Rubber
C0157	Front Upper Plate	C0531	1 Hole Damper Piston $\phi$ 1.6mm
C0158	Front Upright	C0560	2 Hole Damper Piston $\phi$ 1.2mm
C0159	Front Upright Cup	C0564	Rear Long Damper Case
C0160	Pivot Ball	C0565	Rear Long Damper Shaft
C0161	Adjust Nut	C0566	Front Damper Stay
C0162	Rear Upright	C0567	Rear Damper Stay
C0163	Lower Sus. Shaft L	C0568	Damper Cap
C0164	Upper Sus. Shaft	C0569	Damper Cap Bush
C0165	Center Diff. Mount	C0570	Steel Damper Mount
C0166	Die-Cast Center Diff. Mount	C0571	Front Long Spring
C0167	Front Anti Roll Bar Set	C0572	Rear Long Spring
C0171	Front Anti Roll Bar $\phi$ 2.3mm	C0577	Front Damper Set
C0173	Rear Upper Arm Link Ball	C0578	Rear Long Damper Set
C0174	Tension Rod	C0579	2 Hole Damper Piston $\phi$ 1.3mm
C0177	Al. Front Tension Rod	C0601	Bearing (8X16)
C0179	Al. Rear Tension Rod (for Long Chassis)	C0601/1	Bearing (8x16x5)
C0180	Al. Front Sus. Mount	C0603	Clutch Bell Bearing (5X10)
C0181	Al. Rear Sus. Mount	C0605	Servo Saver Bearing
C0182	Lower Arm	C0704	Engine Nut
C0183	Rear Anti-Roll Bar $\phi$ 2.6mm	C0706	Flywheel for 3-Pin Clutch
C0184	Rear Anti-Roll Bar $\phi$ 2.8mm	C0707	Carbon Shoe for 3-Pin Clutch
C0185	Rear Tension Rod	C0708	Spring for 3-Pin Clutch
C0205	Joint Cup	C0710	3-Pin Clutch Set
C0206	Half Shaft for Universal Joint	C0711	Shoe for 3-Pin Clutch
C0207	Universal Joint	C0719	Clutch Bell 13T (5X10 B.B.)
C0208	Wheel Hub	C0720	Clutch Bell 14T (5x10 B.B.)
C0209	Rear Half Shaft	C0721	Clutch Bell 15T (5x 10 B.B.)
C0210	Rear Axle Shaft	C0723	Engine Mount Flat Screw
T0210	O-Ring Set	C0751	3P Clutch Spring $\phi$ 0.9mm
C0211	Bevel Gear	C0752	Engine Mount
C0223	Cup Joint F/R	C0806	Antenna
C0224	Cup Joint Center	C0807	Body Pin
C0227	Spacer (For C0228)	C0808	Ball Link Set
C0228	Diff Gear w/O-Ring	C0853	Fuel Tank
C0250	Center Drive Shaft-S	C0854	Steering Linkage
C0251	Center Drive Shaft-L	C0855	Throttle & Brake Linkage
C0255	Joint Cup (Long)	C0856	Turnbuckle Tie Rod
C0256	Diff. Case	H0855	Ball Link 6mm
C0257	Diff. Gasket	H0856	Stabilizer Link Ball
C0258	Conical Gear	C0857	Fuel Tank Guard
C0259	Spur Gear	C0901	Muffler Stay
C0260	F/R Universal Joint	C0903	Manifold Spring
C0261	Center Universal Joint (S)	C0950	Manifold
C0262	Center Universal Joint (L)	C1010	Nylon Wing (White)
C0263	F/R Axle Shaft	C1011	Nylon Wing (Yellow)
C0264	Joint Shaft	C1016	Body
C0265	Joint Pin	C1121	640/Victory Tire S
C0266	Joint Cup	C1122	640/Vicroty Tire SS
C0267	F/R Drive Shaft	C1123	Spoke Wheel (White)
C0268	Center Drive Shaft (S)	C1123/1	Spoke Wheel (White) 4pcs.
C0269	Center Drive Shaft (L)	C1125	Spoke Wheel (Yellow)
C0304	Brake Set	C1127	480/Victory Tire S
C0350	Radio Plate	C1128	480/Victory Tire H
C0351	Receiver Box	C1129	Inner Foam S
C0352	Battery Holder & Post	C1130	Inner Foam L
C0353	Brake Pad	B0101	Air Filter Set for 21 Buggy
C0354	Brake Disk	B0102	Air Filter for 21 Buggy
C0355	Servo Saver Arm	B0103	Fuel Filter L
C0356	Servo Saver Shaft	B0104	Fuel Filter S
C0357	Servo Saver Pipe	B0115	Fuel Pump
C0358	Servo Saver Spring	B0203	Quick Booster
C0359	Al. Radio Plate Post	B0207	Pocket Booster
C0360	Carbon Mecha. Plate	B0208	DC Adaptor for Pocket Booster

B0209	Battery Booster for 100V	B0417	Color Strap Set 150mm
B0213	Power Pack 900 Futaba Line	B0424	Port Cap for 21
B0214	Power Pack 900 Sanwa Z Line	B0425	Head Protector (Green)
B0230	Pro Starter BII	B0426	Head Protector (Purple)
B0233	12V Battery Code for Starter	B0502	Works Wrench 1.5mm
B0301	Lockfirm Liquid	B0503	Works Wrench 2.0mm
B0302	Air Filter Oil	B0504	Works Wrench 2.5mm
B0303	Engine Maintenance Oil	B0508	Utility Wrench
B0306	Rad-Rez	B0509	Setting Driver for Engine
B0307	Pit de Cleaner	B0510	Camber Gauge
B0308	Super Grease	B0511	Driver for Head Screw
B0309	Air Filter Oil	B0512	Cross Wrench
B0310	Super Silicone #100	B0611	M3x12B/H Tapping Screw
B0311	Super Silicone #150	B0612	M3x15B/H Tapping Screw
B0312	Super Silicone #200	B0613	M3x8B/H Tapping Screw
B0313	Super Silicone #250	B0633	M4x16F/H Tapping Screw
B0314	Super Silicone #300	B0635	M3x12F/H Tapping Screw
B0315	Super Silicone #350	B0640	M4x10F/H Screw
B0316	Super Silicone #400	B0642	M3x12F/H Screw
B0317	Super Silicone for Diff. #10000	B0643	M4x15F/H Cap Screw
B0318	Super Silicone for Diff. #30000	B0644	M4x20F/H Cap Screw
B0319	Super Silicone for Diff. #50000	B0651	M3X12B/H Screw
B0320	Super Silicone for Diff. #100000	B0661	M3X23 Cap Screw
B0321	Super Silicone for Diff. #3000	B0662	M3X8 Cap Screw
B0322	Super Silicone for Diff. #5000	B0663	M3X12 Cap Screw
B0323	Super Silicone for Diff. #7000	B0664	M3X16 Cap Screw
B0324	Super Silicone for Diff. #1000	B0670	M3X3 Set Screw
B0325	Super Silicone #500	B0671	M3X5 Set Screw
B0326	Super Silicone #600	B0672	M3X12 Set Screw
B0327	Super Silicone #700	B0680	M3X4 Set Screw
B0328	Super Silicone #800	B0681	M3X5 Set Screw
B0401	Switch Cover	B0682	M3X8 Set Screw
B0406	Both Side Tape	B0683	M4X12 Set Screw
B0407	Flat Washer 3mm	B0690	M5X5 Set Screw
B0408	Flat Washer 4mm	B0710	M3 Nut
B0410	Color Silicone Pipe (Pink)	B0712	M2.6 Nylon Nut (10 pcs.)
B0411	Color Silicone Pipe (Green)	B0713	SN3 Nylon Nut (10 pcs.)
B0412	Color Silicone Pipe (Yellow)	B0714	SN4 Nylon Nut (10 pcs.)
B0414	Muffler Joint Silicone Pipe L	B0722	φ 2.5 E-Ring
B0416	Color Strap Set 100mm	B0723	φ 3x8x0.5 Washer (10pcs.)