

OP : Optional Parts

| | | | |
|------------|--------------------------------------|----------|--|
| H0072 | INSTRUCTION MANUAL | H0367 | SERVO SAVER SPRING |
| H0073 | DECAL | H0368 | GROMMET |
| D0104R | REAR LOWER SUS. SHAFT | H0369 | VENTILATED BRAKE DISK |
| H0104L | FRONT LOWER SUS. SHAFT | H0370 | RADIO PLATE |
| J0105U | REAR UPPER SUS. SHAFT | H0371 | TH SERVO MOUNT |
| D0105R | KING PIN | H0372 | SERVO SAVER ARM |
| H0107/1 | FRONT STABILIZER BAR | H0373 | RADIO MOUNT PARTS |
| H0131 | FRONT BULKHEAD | H0463 | FRONT BUMPER |
| H0132 | REAR BULKHEAD | H0465 | FRONT BODY MOUNT |
| H0133 | BRAKE BRACKET | H0466 | REAR BODY MOUNT |
| H0134 | REAR LOWER ARM MOUNT | H0467 | REAR BODY MOUNT CENTERING PLATE |
| H0135 | FRONT UPPER ARM | H0468 | REAR BOYD MOUNT CENTERING SHAFT |
| H0136 | REAR UPPER ARM | H0469 | REAR BODY MOUNT ARM SHAFT |
| H0137 | FRONT LOWER ARM | H0470 | REAR BODY MOUNT ARM STOPPER |
| H0138 | REAR LOWER ARM | H0471 | REAR BODY MOUNT ARM PIN |
| H0139 | FRONT UPRIGHT | H0472 | CHASSIS |
| H0140 | REAR UPRIGHT | OP H0473 | FRONT BODY MOUNT PLATE CFRP |
| H0141 | FRONT ANTI-ROLL BAR HOLDER | OP H0474 | CHASSIS |
| H0142 | RADIO PLATE MOUNT | D0506 | REAR DAMPER SHAFT |
| H0143 | MIDDLE SHAFT BRACKET | D0508 | DIAPHRAGM |
| H0144 | KING PIN BALL CUP | D0509 | O-RING SET |
| H0145 | ADJUST NUT | H0510 | DAMPER PISTON |
| OP H0146 | SUS. ARM SPACER | H0513 | SPRING ADJUSTER |
| OP H0158 | FRONT UPRIGHT | OP H0516 | FRONT DAMPER SPRING BLUE ϕ 2.0mm |
| H0161 | FRONT UPPER SUS. SHAFT | OP H0525 | FRONT DAMPER SPRING GRAY ϕ 1.8mm |
| H0163 | REAR ANTI-ROLL BAR | H0526 | FRONT DAMPER SPRING WHITE ϕ 1.9mm |
| H0164 | ROLL BAR | OP H0529 | REAR DAMPER SPRING GRAY ϕ 1.8mm |
| H0180 | REAR UPRIGHT BALL | H0530 | REAR DAMPER SPRING WHITE ϕ 1.9mm |
| H0181 | REAR UPRIGHT SPACER | OP H0531 | REAR DAMPER SPRING PINK ϕ 2.0mm |
| OP H0185 | REAR ADJUSTABLE ANTI-ROLL BAR SET | OP H0532 | REAR DAMPER SPRING RED ϕ 2.0mm |
| OP H0186 | REAR ADJUSTABLE ANTI-ROLL BAR | H0554 | DAMPER CAP |
| OP H0187 | TITANIUM KING PIN BALL (2 pcs.) | H0555 | DAMPER CAP PARTS |
| OP H0187/1 | TITANIUM KING PIN BALL (8 pcs.) | OP H0558 | DAMPER PISTON (ϕ 1.2) |
| H0205 | PULLEY HUB | OP H0559 | DAMPER PISTON (ϕ 1.3) |
| D0206 | INNER DRIVE JOINT | H0560 | FRONT DAMPER STAY |
| OP H0208 | FRONT AXLE SHAFT | H0561 | REAR DAMPER STAY |
| J0209 | MIDDLE SHAFT | H0562 | DAMPER CASE |
| H0222 | REAR AXLE SHAFT | H0563 | OIL SEAL CAP |
| D0240 | BELT S 6mm | H0564 | DAMPER SET |
| H0240 | BELT S 8mm | H0565 | DAMPER CAP PARTS |
| H0241 | BELT L 6mm | D0601 | BEARING (12x21) |
| H0252 | FRONT ONE WAY DRIVE AXLE | H0601 | BEARING (12x18) |
| OP H0253 | FRONT DRIVE SHAFT | D0602 | BEARING (6x13) |
| H0255 | BRAKE PULLEY ADAPTER | C0603 | CLUTCH BEARING (5x10) |
| H0256 | 2 SPEED SHAFT | D0603 | 5mm THRUST BEARING |
| H0257 | 2 SPEED ADAPTER | H0603 | FLANGE BEARING FOR BELT TENSIONER |
| H0268 | AXLE WASHER | C0605 | BEARING FOR SERVO SAVER (6x10) |
| OP H0269 | TITANIUM MIDDLE SHAFT | H0608 | BEARING FOR 2nd. GEAR HOUSING |
| H0270 | FRONT UNIVERSAL JOINT SET | H0704 | ENGINE NUT |
| H0271 | FRONT AXLE SHAFT FOR UNIVERSAL | OP H0707 | CLUTCH SHOE |
| H0272 | FRONT DRIVE SHAFT FOR UNIVERSAL | H0710 | CLUTCH BELL |
| H0273 | JOINT SHAFT FOR UNIVERSAL | H0721 | PRESSURE PLATE |
| H0274 | ROLLER PIN ϕ 2.5x11.8 (10 pcs.) | H0751 | FLYWHEEL |
| H0275 | FRONT WHEEL CHANGE LEVER | OP H0752 | CENTRIFUGAL SHOE |
| H0279 | REAR WHEEL CHANGE LEVER | H0753 | SPRING CUP |
| H0280 | PULLEY SET | H0755 | SPRING ADJUST NUT |
| OP H0281 | 1st. GEAR 48T | H0756 | BEARING STOPPER |
| H0282 | 1st. GEAR 49T | OP H0757 | 1st. GEAR 16T |
| OP H0283 | 1st. GEAR 50T | H0758 | 1st. GEAR 17T |
| OP H0284 | 2nd. GEAR 45T | OP H0759 | 1st. GEAR 18T |
| H0285 | 2nd. GEAR 46T | OP H0760 | 2nd. GEAR 19T |
| OP H0286 | 2nd. GEAR 47T | H0761 | 2nd. GEAR 20T |
| H0287 | SHOE FOR 2 SPEED GEAR BOX | OP H0762 | 2nd. GEAR 21T |
| H0288 | HOUSING FOR 1st. GEAR | OP H0764 | CLUTCH SPRING HARD |
| H0289 | HOUSING FOR 2nd. GEAR | H0765 | CLUTCH SHOE (GRAY) |
| H0290 | REAR SOLID AXLE | H0766 | LIGHT WEIGHT CENTRIFUGAL SHOE |
| H0291 | REAR DRIVE SHAFT | H0767 | CLUTCH SPRING SUPER HARD |
| H0292 | BELT TENSIONER PLATE | OP H0769 | CLUTCH SHOE (RED) |
| H0293 | BELT TENSIONER SHAFT | H0770 | ENGINE MOUNT |
| H0295 | SPRING FOR 2 SPEED GEAR BOX | H0771 | CLUTCH SET |
| H0353 | BRAKE CAM | OP H0772 | ONE PIECE ENGINE MOUNT |
| H0354 | BRAKE PLATE | H0801A | STEERING ROD |
| OP H0355 | BRAKE PAD | H0802 | ENGINE CONTROL LINKAGE |
| H0359 | BRAKE PAD (PTFE) | D0806 | ANTENNA PIPE |
| H0362 | SERVO MOUNT PARTS | D0807 | BODY PIN |
| H0365 | SERVO SAVER SHAFT | H0851 | E-RING SET |
| H0366 | SERVO SAVER PIPE | H0852 | SNAP RING SET |

| | | | |
|-----------------------------|---------------------------------|---------|---|
| H0853 | ROLLER PIN 3x11.6 | B0519 | (+) #2 SCREW DRIVER |
| H0854 | ROLLER PIN SET | B0519/1 | (+) #2 SCREW DRIVER TIP |
| H0855 | BALL LINK φ6mm | B0520 | (+) #1 SCREW DRIVER |
| H0856 | STABILIZER LINK BALL | B0520/1 | (+) #1 SCREW DRIVER TIP |
| H0857 | TURN BUCKLE ROD(22mm) | B0521 | (-) 1.0 SCREW DRIVER |
| H0858 | BALL LINK φ6mm (S) | B0521/1 | (-) 1.0 SCREW DRIVER TIP |
| OP H0862 | TITANIUM STEERING ROD | B0522 | (-) 0.5 SCREW DRIVER |
| OP H0863 | TITANIUM TURN BUCKLE ROD (22mm) | B0522/1 | (-) 0.5 SCREW DRIVER TIP |
| H0864 | FUEL TANK CAP | B0523 | 1.5mm Hex. WRENCH |
| H0866 | FUEL TANK | B0523/1 | 1.5mm Hex. WRENCH TIP |
| H0867 | PIVOT BALL | B0524 | 2.0mm Hex. WRENCH |
| OP H0868 | TITANIUM SCREW SET A | B0524/1 | 2.0mm Hex. WRENCH TIP |
| OP H0869 | TITANIUM SCREW SET B | B0525 | 2.5mm Hex. WRENCH |
| C0901 | MUFFLER STAY | B0525/1 | 2.5mm Hex. WRENCH TIP |
| OP H0901 | MANIFOLD SPRING | B0526 | 3.0mm Hex. WRENCH |
| H0952 | WIRE FOR MUFFLER | B0526/1 | 3.0mm Hex. WRENCH TIP |
| OP H1006 | REAR SPOILER ADJ. SCREW | B0527 | 2.0mm Ball-Hex. WRENCH |
| OP H1008 | LOLA VDS | B0527/1 | 2.0mm Ball-Hex. WRENCH TIP |
| OP H1009 | BODY STIFFENER | B0528 | 2.5mm Ball-Hex. WRENCH |
| OP H1010 | REAR SPOILER SET | B0528/1 | 2.5mm Ball-Hex. WRENCH TIP |
| OP H1011 | REAR SPOILER | B0529 | PROSPEC TOOL SET |
| OP H1101 | FRONT WHEEL (WHITE) | B0530 | 2.0mm Hex. WRENCH TIP FOR ELECTRIC DRIVER |
| OP H1102 | REAR WHEEL (WHITE) | B0531 | 2.5mm Hex. WRENCH TIP FOR ELECTRIC DRIVER |
| <u>Other Optional Parts</u> | | | |
| B0103 | FUEL FILTER L | B0663 | SG3x12 CAP SCREW |
| B0104 | FUEL FILTER S | B0664 | SG3x16 CAP SCREW |
| B0113 | AIR FILTER FOR 210N-ROAD | B0670 | SK3x3 SET SCREW |
| B0115 | FUEL PUMP 500ml | B0671 | SK3x5 SET SCREW |
| B0116 | PRESSURE CHAMBER SET | B0672 | SK3x12 SET SCREW |
| B0117 | PRESSURE CHAMBER MOUNT | B0675 | SK3x16 SET SCREW |
| B0203 | QUICK BOOSTER | B0681 | SK4x5 SET SCREW |
| B0207 | POCKET BOOSTER | B0682 | SK4x8 SET SCREW |
| B0208 | ADAPTER FOR POCKET BOOSTER | B0690 | SK5x5 SET SCREW |
| B0209 | BATTERY FOR POCKET BOOSTER | B0712 | SN2.6 NYLON NUT (10 pcs.) |
| B0213 | POWER PACK 900 (FUTABA) | B0713 | SN3 NYLON NUT (10 pcs.) |
| B0214 | POWER PACK 900 (SANWA) | B0714 | SN4 NYLON NUT (10 pcs.) |
| B0220 | PRO STARTER RII | B0722 | OE-2.5 E-RING |
| B0233 | BATTERY CODE FOR RII/BII | B0723 | OW3x8x0.5 WASHER |
| B0301 | LOCK FIRM LIQUID | B0724 | OE-3 E-RING |
| B0303 | ENGINE MAINTENANCE OIL | B0730 | SiG 3x8 B/H SCREW |
| B0306 | RAD REZ | B0731 | SiG 3x10 B/H SCREW |
| B0308 | SUPER GREASE | B0732 | SiG 3x12 B/H SCREW |
| B0316 | SUPER SILICON #400 | B0733 | SiG 3x14 B/H SCREW |
| B0325 | SUPER SILICON #500 | B0734 | SiG 3x16 B/H SCREW |
| B0326 | SUPER SILICON #600 | B0735 | SiG 3x18 B/H SCREW |
| B0327 | SUPER SILICON #700 | B0736 | SiG 3x6 B/H SCREW |
| B0328 | SUPER SILICON #800 | B0740 | SJG 3x8 F/H SCREW |
| B0329 | AIR FILTER OIL | B0741 | SJG 3x10 F/H SCREW |
| B0330 | SUPER JOINT GREASE | B0742 | SJG 3x6 F/H SCREW |
| B0332 | SUPER SILICON #450 | B0743 | SJG 3x12 F/H SCREW |
| B0333 | SUPER SILICON #550 | B0746 | SJG 4x8 F/H SCREW |
| B0406 | BOTH SIDE TAPE | B0747 | SJG 4x10 F/H SCREW |
| B0407 | FLAT WASHER 3mm | B0750 | SJG 4x12 F/H SCREW |
| B0408 | FLAT WASHER 4mm | B0730T | SiG 3x8T B/H TITANIUM SCREW |
| B0410 | COLOR SILICON PIPE PINK | B0731T | SiG 3x10T B/H TITANIUM SCREW |
| B0411 | COLOR SILICON PIPE GREEN | B0732T | SiG 3x12T B/H TITANIUM SCREW |
| B0412 | COLOR SILICON PIPE YELLOW | B0733T | SiG 3x14T B/H TITANIUM SCREW |
| B0413 | COLOR SILICON PIPE GRAY | B0734T | SiG 3x16T B/H TITANIUM SCREW |
| B0416 | COLOR STRAP SET 100mm | B0735T | SiG 3x18T B/H TITANIUM SCREW |
| B0417 | COLOR STRAP SET 150mm | B0736T | SiG 3x6T B/H TITANIUM SCREW |
| B0424 | PORT CAP (L+M) | B0740T | SJG 3x8T F/H TITANIUM SCREW |
| B0426 | HEAD PROTECTOR (PURPLE) | B0741T | SJG 3x10T F/H TITANIUM SCREW |
| B0506 | SNAP RING PLIERS | B0742T | SJG 3x6T F/H TITANIUM SCREW |
| B0508 | UTILITY WRENCH | B0743T | SJG 3x12T F/H TITANIUM SCREW |
| B0509 | SETTING DRIVER FOR ENGINE | B0746T | SJG 4x8T F/H TITANIUM SCREW |
| B0510 | CAMBER GAUGE | B0747T | SJG 4x10T F/H TITANIUM SCREW |
| B0513 | PINION GEAR TOOL | B0750T | SJG 4x12T F/H TITANIUM SCREW |
| B0514 | CLUTCH SPRING ADJUSTER TOOL | P0218 | STICKER FLAG & FLAME |