

OP : Optional Parts

H0076	INSTRUCTION MANUAL		
H0077	DECAL MRX4-R		
D0104R	REAR LOWER SUS. SHAFT		
H0104L	FRONT LOWER SUS. SHAFT		
J0105U	REAR UPPER SUS. SHAFT		
D0105R	KING PIN		
H0107/1	FRONT STABILIZER BAR		
H0133	BRAKE BRACKET		
H0134	REAR LOWER ARM MOUNT		
H0135	FRONT UPPER ARM		
H0136	REAR UPPER ARM		
H0137	FRONT LOWER ARM		
H0138	REAR LOWER ARM		
H0139	FRONT UPRIGHT		
H0140	REAR UPRIGHT		
H0141	FRONT ANTI-ROLL BAR HOLDER		
H0142	RADIO PLATE MOUNT		
H0143	MIDDLE SHAFT BRACKET		
H0144	KING PIN BALL CUP		
H0145	ADJUST NUT		
OP H0146	SUS. ARM SPACER		
H0147	REAR UPPER ARM SET		
H0148	FRONT BULKHEAD		
H0149	REAR BULKHEAD		
T0154	ECCENTRIC HUB		
OP H0158	FRONT UPRIGHT		
H0161	FRONT UPPER SUS. SHAFT		
H0163	REAR ANTI-ROLL BAR		
H0164	ROLL BAR		
H0180	REAR UPRIGHT BALL		
H0181	REAR UPRIGHT SPACER		
OP H0185	REAR ADJUSTABLE ANTI-ROLL BAR SET		
OP H0186	REAR ADJUSTABLE ANTI-ROLL BAR		
OP H0187	TITANIUM KING PIN BALL (2 pcs.)		
OP H0187/1	TITANIUM KING PIN BALL (8 pcs.)		
H0205	PULLEY HUB		
D0206	INNER DRIVE JOINT		
OP H0208	FRONT AXLE SHAFT		
J0209	MIDDLE SHAFT		
H0222	REAR AXLE SHAFT		
D0240	BELT S 6mm		
H0240	BELT S 8mm		
H0241	BELT L 6mm		
H0245	BELT S 6mm RUBBER		
H0246	BELT S 9mm RUBBER		
H0247	BELT L 6mm RUBBER		
H0252	FRONT ONE WAY DRIVE AXLE		
OP H0253	FRONT DRIVE SHAFT		
H0255	BRAKE PULLEY ADAPTER		
H0256	2 SPEED SHAFT		
H0257	2 SPEED ADAPTER		
H0268	AXLE WASHER		
OP H0269	TITANIUM MIDDLE SHAFT		
H0270	FRONT UNIVERSAL JOINT SET		
H0271	FRONT AXLE SHAFT FOR UNIVERSAL		
H0272	FRONT DRIVE SHAFT FOR UNIVERSAL		
H0273	JOINT SHAFT FOR UNIVERSAL		
H0274	ROLLER PIN $\phi$ 2.5x11.8 (10 pcs.)		
H0275	FRONT WHEEL CHANGE LEVER		
H0279	REAR WHEEL CHANGE LEVER		
H0280	PULLEY SET		
OP H0281	1st. GEAR 48T		
H0282	1st. GEAR 49T		
OP H0283	1st. GEAR 50T		
OP H0284	2nd. GEAR 45T		
H0285	2nd. GEAR 46T		
OP H0286	2nd. GEAR 47T		
H0287	SHOE FOR 2 SPEED GEAR BOX		
H0288	HOUSING FOR 1st. GEAR		
H0289	HOUSING FOR 2nd. GEAR		
H0290	REAR SOLID AXLE		
H0291	REAR DRIVE SHAFT		
H0292	BELT TENSIONER PLATE		
H0293	BELT TENSIONER SHAFT		
H0295	SPRING FOR 2 SPEED GEAR BOX		
H0353	BRAKE CAM		
H0354	BRAKE PLATE		
OP H0355	BRAKE PAD		
H0359	BRAKE PAD (PTFE)		
H0362	SERVO MOUNT PARTS		
H0365	SERVO SAVER SHAFT		
H0366	SERVO SAVER PIPE		
H0367	SERVO SAVER SPRING		
H0368	GROMMET		
H0369	VENTILATED BRAKE DISK		
H0370	RADIO PLATE		
H0371	TH SERVO MOUNT		
H0372	SERVO SAVER ARM		
H0373	RADIO MOUNT PARTS		
H0463	FRONT BUMPER		
H0465	FRONT BODY MOUNT		
H0466	REAR BODY MOUNT		
H0467	REAR BODY MOUNT CENTERING PLATE		
H0468	REAR BOYD MOUNT CENTERING SHAFT		
H0469	REAR BODY MOUNT ARM SHAFT		
H0470	REAR BODY MOUNT ARM STOPPER		
H0471	REAR BODY MOUNT ARM PIN		
H0472	CHASSIS		
OP H0473	FRONT BODY MOUNT PLATE CFRP		
OP H0474	CHASSIS		
D0506	REAR DAMPER SHAFT		
D0508	DIAPHRAGM		
D0509	O-RING SET		
H0510	DAMPER PISTON		
H0513	SPRING ADJUSTER		
OP H0516	FRONT DAMPER SPRING BLUE $\phi$ 2.0mm		
OP H0525	FRONT DAMPER SPRING GRAY $\phi$ 1.8mm		
H0526	FRONT DAMPER SPRING WHITE $\phi$ 1.9mm		
OP H0529	REAR DAMPER SPRING GRAY $\phi$ 1.8mm		
H0530	REAR DAMPER SPRING WHITE $\phi$ 1.9mm		
OP H0531	REAR DAMPER SPRING PINK $\phi$ 2.0mm		
OP H0532	REAR DAMPER SPRING RED $\phi$ 2.0mm		
H0554	DAMPER CAP		
H0555	DAMPER CAP PARTS		
OP H0558	DAMPER PISTON ( $\phi$ 1.2)		
OP H0559	DAMPER PISTON ( $\phi$ 1.3)		
H0562	DAMPER CASE		
H0563	OIL SEAL CAP		
H0564	DAMPER SET		
H0565	DAMPER CAP PARTS		
H0566	FRONT DAMPER STAY		
H0567	REAR DAMPER STAY		
H0568	DAMPER CASE LONG (REAR)		
H0569	REAR DAMPER SET		
D0601	BEARING (12x21)		
H0601	BEARING (12x18)		
D0602	BEARING (6x13)		
C0603	CLUTCH BEARING (5x10)		
D0603	5mm THRUST BEARING		
H0603	FLANGE BEARING FOR BELT TENSIONER		
C0605	BEARING FOR SERVO SAVER (6x10)		
H0608	BEARING FOR 2nd. GEAR HOUSING		
H0704	ENGINE NUT		
OP H0707	CLUTCH SHOE		
H0710	CLUTCH BELL		
H0721	PRESSURE PLATE		
H0751	FLYWHEEL		
OP H0752	CENTRIFUGAL SHOE		
H0753	SPRING CUP		
H0755	SPRING ADJUST NUT		
H0756	BEARING STOPPER		
OP H0757	1st. GEAR 16T		
H0758	1st. GEAR 17T		
OP H0759	1st. GEAR 18T		
OP H0760	2nd. GEAR 19T		
H0761	2nd. GEAR 20T		
OP H0762	2nd. GEAR 21T		
OP H0764	CLUTCH SPRING HARD		
H0765	CLUTCH SHOE (GRAY)		
H0766	LIGHT WEIGHT CENTRIFUGAL SHOE		
H0767	CLUTCH SPRING SUPER HARD		
OP H0769	CLUTCH SHOE (RED)		
H0770	ENGINE MOUNT		
H0771	CLUTCH SET		

OP H0772	ONE PIECE ENGINE MOUNT	B0510	CAMBER GAUGE
OP H0773	CLUTCH SHOE (YELLOW)	B0513	PINION GEAR TOOL
H0801A	STEERING ROD	B0514	CLUTCH SPRING ADJUSTER TOOL
H0802	ENGINE CONTROL LINKAGE	B0519	(+) #2 SCREW DRIVER
D0806	ANTENNA PIPE	B0519/1	(+) #2 SCREW DRIVER TIP
D0807	BODY PIN	B0520	(+) #1 SCREW DRIVER
H0851	E-RING SET	B0520/1	(+) #1 SCREW DRIVER TIP
H0852	SNAP RING SET	B0521	(-) 1.0 SCREW DRIVER
H0853	ROLLER PIN 3x11.6	B0521/1	(-) 1.0 SCREW DRIVER TIP
H0854	ROLLER PIN SET	B0522	(-) 0.5 SCREW DRIVER
H0855	BALL LINK φ6mm	B0522/1	(-) 0.5 SCREW DRIVER TIP
H0856	STABILIZER LINK BALL	B0523	1.5mm Hex. WRENCH
H0857	TURN BUCKLE ROD(22mm)	B0523/1	1.5mm Hex. WRENCH TIP
H0858	BALL LINK φ6mm (S)	B0524	2.0mm Hex. WRENCH
OP H0862	TITANIUM STEERING ROD	B0524/1	2.0mm Hex. WRENCH TIP
OP H0863	TITANIUM TURN BUCKLE ROD (22mm)	B0525	2.5mm Hex. WRENCH
H0864	FUEL TANK CAP	B0525/1	2.5mm Hex. WRENCH TIP
H0866	FUEL TANK	B0526	3.0mm Hex. WRENCH
H0867	PIVOT BALL	B0526/1	3.0mm Hex. WRENCH TIP
OP H0868	TITANIUM SCREW SET A	B0527	2.0mm Ball-Hex. WRENCH
OP H0869	TITANIUM SCREW SET B	B0527/1	2.0mm Ball-Hex. WRENCH TIP
C0901	MUFFLER STAY	B0528	2.5mm Ball-Hex. WRENCH
OP H0901	MANIFOLD SPRING	B0528/1	2.5mm Ball-Hex. WRENCH TIP
H0952	WIRE FOR MUFFLER	B0529	PROSPEC TOOL SET
OP H1006	REAR SPOILER ADJ. SCREW	B0530	2.0mm Hex. WRENCH TIP FOR ELECTRIC DRIVER
OP H1008	LOLA VDS	B0531	2.5mm Hex. WRENCH TIP FOR ELECTRIC DRIVER
OP H1009	BODY STIFFENER	B0532	PINION GEAR TOOL
OP H1010	REAR SPOILER SET	B0663	SG3x12 CAP SCREW
OP H1011	REAR SPOILER	B0664	SG3x16 CAP SCREW
OP H1101	FRONT WHEEL (WHITE)	B0670	SK3x3 SET SCREW
OP H1102	REAR WHEEL (WHITE)	B0671	SK3x5 SET SCREW
<u>Other Optional Parts</u>			
B0010	"AIR BOOSTER" AIR FILTER SET	B0672	SK3x12 SET SCREW
B0011	"AIR BOOSTER" AIR FILTER	B0675	SK3x16 SET SCREW
B0103	FUEL FILTER L	B0681	SK4x5 SET SCREW
B0104	FUEL FILTER S	B0682	SK4x8 SET SCREW
B0113	AIR FILTER FOR 210N-ROAD	B0690	SK5x5 SET SCREW
B0115	FUEL PUMP 500ml	B0712	SN2.6 NYLON NUT (10 pcs.)
B0116	PRESSURE CHAMBER SET	B0713	SN3 NYLON NUT (10 pcs.)
B0117	PRESSURE CHAMBER MOUNT	B0714	SN4 NYLON NUT (10 pcs.)
B0203	QUICK BOOSTER	B0722	OE-2.5 E-RING
B0207	POCKET BOOSTER	B0723	OW3x8x0.5 WASHER
B0208	ADAPTER FOR POCKET BOOSTER	B0724	OE-3 E-RING
B0209	BATTERY FOR POCKET BOOSTER	B0730	SiG 3x8 B/H SCREW
B0213	POWER PACK 1000 (FUTABA)	B0731	SiG 3x10 B/H SCREW
B0214	POWER PACK 1000 (SANWA)	B0732	SiG 3x12 B/H SCREW
B0220	PRO STARTER RII	B0733	SiG 3x14 B/H SCREW
B0233	BATTERY CODE FOR RII/BII	B0734	SiG 3x16 B/H SCREW
B0301	LOCK FIRM LIQUID	B0735	SiG 3x18 B/H SCREW
B0303	ENGINE MAINTENANCE OIL	B0736	SiG 3x6 B/H SCREW
B0306	RAD REZ	B0740	SJG 3x8 F/H SCREW
B0308	SUPER GREASE	B0741	SJG 3x10 F/H SCREW
B0316	SUPER SILICON #400	B0742	SJG 3x6 F/H SCREW
B0325	SUPER SILICON #500	B0743	SJG 3x12 F/H SCREW
B0326	SUPER SILICON #600	B0746	SJG 4x8 F/H SCREW
B0327	SUPER SILICON #700	B0747	SJG 4x10 F/H SCREW
B0328	SUPER SILICON #800	B0750	SJG 4x12 F/H SCREW
B0329	AIR FILTER OIL	B0730T	SiG 3x8T B/H TITANIUM SCREW
B0330	SUPER JOINT GREASE	B0731T	SiG 3x10T B/H TITANIUM SCREW
B0332	SUPER SILICON #450	B0732T	SiG 3x12T B/H TITANIUM SCREW
B0333	SUPER SILICON #550	B0733T	SiG 3x14T B/H TITANIUM SCREW
B0406	BOTH SIDE TAPE	B0734T	SiG 3x16T B/H TITANIUM SCREW
B0407	FLAT WASHER 3mm	B0735T	SiG 3x18T B/H TITANIUM SCREW
B0408	FLAT WASHER 4mm	B0736T	SiG 3x6T B/H TITANIUM SCREW
B0410	COLOR SILICON PIPE PINK	B0740T	SJG 3x8T F/H TITANIUM SCREW
B0411	COLOR SILICON PIPE GREEN	B0741T	SJG 3x10T F/H TITANIUM SCREW
B0412	COLOR SILICON PIPE YELLOW	B0742T	SJG 3x6T F/H TITANIUM SCREW
B0413	COLOR SILICON PIPE GRAY	B0743T	SJG 3x12T F/H TITANIUM SCREW
B0424	PORT CAP (L+M)	B0746T	SJG 4x8T F/H TITANIUM SCREW
B0426	HEAD PROTECTOR (PURPLE)	B0747T	SJG 4x10T F/H TITANIUM SCREW
B0506	SNAP RING PLIERS	B0750T	SJG 4x12T F/H TITANIUM SCREW
B0509	SETTING DRIVER FOR ENGINE	P0218	STICKER FLAG & FLAME